

Experiment #4 Introduction to Digital Multimeters, Oscilloscopes & Function Generators

4.1 Introduction:

At each station in our electric-circuits laboratories a standard set of instruments is available to enable you to conduct your investigations of circuit behaviour. These instruments are capable of providing the following:

- Generate test signals such as sinusoidal, triangular, and square waveforms with adjustable amplitude and frequency. These signals can be level-shifted [up or down] with the addition of a dc-offset component,
- Measure dc and/or ac voltage & current, resistance, and frequency, and
- Display voltage waveforms on a CRT.

This experiment introduces these instruments and demonstrates their capabilities and limitations.

4.2 Prelab Assignment:

Read the Appendix-section associated with this experiment and familiarize yourself with the various controls of each instrument.

4.3 Procedure:

- 1- Connect the dc-circuit shown in Fig (4.1). Set the oscilloscope controls as follows: Signal Coupling (**CHx MENU** → *Coupling*) ☛ **dc**, Y-Position (**VERTICAL POSITION** knobs) ☛ **screen centre**, and Vertical Sensitivity (**VOLTS/DIV** knobs) ☛ **1V/div** for both channels "1" & "2".

Connect channels "1" & "2" to display the voltage waveforms @ nodes (1) & (2) respectively.




Fig (4.1)

- 2- Use the oscilloscope to measure the voltages @ nodes (1) & (2).

$$V_{(1)} = 4.000 \text{ V} \quad \& \quad V_{(2)} = 1.459 \text{ V}$$

- 3- Use the DMM to measure the voltages @ nodes (1) & (2).

$$V_{(1)} = 4 \text{ V} \quad \& \quad V_{(2)} = 1.459 \text{ V}$$

- 4- With the oscilloscope connected as in step #1, set the following additional controls as: Horizontal Sensitivity (SEC/DIV knob) \leftarrow 0.2 msec/div, Trigger Source (TRIG MENU \rightarrow Source) \leftarrow CH1, and Trigger Slope (TRIG MENU \rightarrow Slope) \leftarrow Rising.

Replace the dc-source in the circuit of Fig (4.1) with the **function generator**. Set the controls of the function generator to provide a **sinusoidal** voltage of **2V (peak)** with a frequency of about **1kHz @ node (1)**.

Use the DMM to measure the **voltage & frequency** [using the dual display of the DMM] of the signal @ node (1). Adjust the frequency of the function generator to exactly **1kHz**.

$$[\text{DMM readings: Frequency} = 10^3 \text{ Hz} \quad \& \quad V_{(1)} = 4.702 \text{ V.}]$$

- 5- Set the "**waveform-select**" control of the function generator to **square wave**, and use the DMM to measure the voltage & frequency @ node (1).

$$[\text{DMM readings: Frequency} = 10^3 \text{ Hz} \quad \& \quad V_{(1)} = 8.000 \text{ V.}]$$

- 6- Set the waveform-select control of the function generator to **triangular wave**, and use the DMM to measure the voltage & frequency @ node (1).

$$[\text{DMM readings: Frequency} = 10^3 \text{ Hz} \quad \& \quad V_{(1)} = 2.914 \text{ V.}]$$

- 7- Use the "**dc-offset**" control of the function generator to provide a **triangular** wave of **4V (peak-to-peak)** with an **average value of 2V** at a frequency of **1kHz @ node (1)**. Note that the amplitude of the waveform is now fluctuating in the voltage range: **0.0V to 4V @ 1kHz**. Use the DMM to measure each of the following voltage entities @ node (1):

- | | | |
|---------------------------|-------------------------|----------------|
| a) The dc-component..... | $V_{(1)}$ [dc-value] | = 1.532 V, |
| b) The ac-component..... | $V_{(1)}$ [ac-value] | = 2.578 V, and |
| c) The [ac + dc]-value... | $V_{(1)}$ [ac+dc-value] | = 2.999 V. |

- 8- Set the controls of the function generator [with the help of the oscilloscope] to provide a sinusoidal signal of **20mV (peak)** with an average value of **2V** at a frequency of **1kHz @ node (1)**.

{Note that the present settings of the oscilloscope controls will not enable you to perform the above step !!}

[Hint: Use the **dc/ac-coupling** & Vertical (Voltage) Sensitivity controls of Channel "1" to separately set accurately the dc & ac components of the desired signal]

Use the DMM to measure the dc & ac components of the voltage @ node (1), and record your measurements in table (4.1).

- 9- Set the "frequency" control of function generator to each of the values listed in table (4.1), and repeat the above step.

Table (4.1) [DMM measurements]

Frequency (kHz)	DC Component (V)	AC Component (mV)
1.0	2	14.9
10.0	1.515	14.97
100.0	1.514	14.559
1000.0	1.510	14.507

- 10- Connect the circuit shown in Fig (4.2). Connect channels "1" & "2" of the oscilloscope to node (1) & (2), respectively. Note Channel 2 will now display a scaled-up version of the current = $(10,000) \times i(t)$. Set the oscilloscope controls as follows:

Signal Coupling (**CHx MENU** → **Coupling**) ← **ac**, Y-Position (**VERTICAL POSITION** knobs) ← **screen centre**, and Vertical Sensitivity (**VOLTS/DIV** knobs) ← **1V/div** for both channels "1" & "2", Horizontal Sensitivity (**SEC/DIV** knob) ← **0.1 msec/div**, Trigger Source (**TRIG MENU** → **Source**) ← **CH1**, and Trigger Slope (**TRIG MENU** → **Slope**) ← **Rising**.

Set the controls of the function generator to provide a **sinusoidal** voltage of **4V (peak)** with a frequency of about **1kHz @ node (1)**.

Note the displays of the waveforms of $V_{(1)}(t)$ and $i(t)$ are both sinusoids with the same frequency, but with a different magnitude and phase angle.




Fig (4.2)

- 11- Use the oscilloscope to measure the phase angle (θ°) of $i(t)$ relative to $V_{(1)}(t)$. This measurement can be performed in **one-out-of-two** ways depending on the mode of operation of the oscilloscope [(**Y-Time**) or (**X-Y**) mode]:

Phase Measurement

A) With The Oscilloscope In The Y-Time Display Mode:

Proceed by setting the oscilloscope controls as follows:

First: Set the Y-Position (VERTICAL POSITION knobs) for both "1" & "2" screen centre, and Horizontal Sensitivity (SEC/DIV knob) to display about **one period** of the **Channel 1** display. Adjust Trigger Level (LEVEL knob) to trigger the **Channel 1** display @ the positive-going **zero crossing** instant, and move this point (with **X-Position** (HORIZONTAL POSITION knob) adjustment) to the left end of the display.

Second: Using Horizontal Controls (HORIZ MENU → Window Zone) to set **one-half period** of the **Channel 1** display to occupy **exactly nine divisions** along the x-axis.

[The x-axis is now calibrated for phase-angle measurements with a scale of 20°/div.]

Measure the phase angle (θ°) and record your result in table (4.2).

B) With The Oscilloscope In The X-Y Display Mode:

Proceed by setting the oscilloscope controls as follows:

Set Display Format (DISPLAY → Format) of the oscilloscope to **XY** mode. Note that the oscilloscope is now using the signal from Channel 1 to control the X coordinate and the signal from Channel 2 to control the Y coordinate. The oscilloscope is now operating in the X-Y display mode.

The vertical deflection is now controlled by the current $i(t)$, and the horizontal deflection is controlled by the voltage $V_{(1)}(t)$.

Generally, the X-Y display [usually called a "**Lissajous pattern**"] is an ellipse; the ratio of [its intersection with the Y-axis (y_0)]-to-[its maximum vertical deflection (y_m)] is used to find the phase angle (θ°) as indicated in Fig (4.3).

Measure the phase angle (θ°) and record your result in table (4.2)

(Table 4.2) [Phase angle (θ°) of $i(t)$ wrt $V_{(1)}(t)$]

Y-Time-display mode	X-Y-dispaly mode




Fig (4.3)

4.4 Conclusion:

- 1- Compare your measurements from steps #2 & 3. Which set of measurements would you consider to be more accurate, and why?

both gave the exact same value so both are equally accurate

- 2- The DMM ac-reading is called the "root-mean-square (RMS)" value of the signal (voltage or current) waveform. For standard waveforms, such as sinusoid, square, and triangular, the RMS-value is related to the peak-value of the signal as follows:

Type of waveform	[RMS-value] / [peak-value]
Sinusoid	$[2]^{-0.5}$ $\frac{1}{\sqrt{2}}$
Square	1
Triangular	$[3]^{-0.5}$ $\frac{1}{\sqrt{3}}$

Use the above table to check whether your measurements from steps #4, 5, and 6 are accurate enough.

Sinusoid: 4.702

Square: $4.702 \times \frac{\sqrt{2}}{2} = 3.325$

Triangular: $4.702 \times \frac{\sqrt{3}}{3} = 2.714$

- 3- Under which conditions would you set the oscilloscope coupling-control to ac?

when I am measuring AC voltage

no my measurements were not accurate

- 4- Discuss the results of your measurements listed in table (4.1).

Frequency has little to no change on the AC and DC values

- 5- In comparing the two methods of phase measurement [step #11], which one do you think is more accurate, and why?